

MEASUREMENT DIRECTION

HOW TO MEASURE A PLACKET

REVISED 02/20/09

BEFORE MEASURING:

REVIEW FIGURE 4 FOR REFERENCE!

SURFACE USED FOR GARMENT MEASURING SHOULD BE CLEAN AND SMOOTH. DO NOT USE FABRIC COVERED SURFACES FOR GARMENT MEASURING.

LAY GARMENT FLAT ON SURFACE, FACE UP, SMOOTHED WITH NO WRINKLES AND WITH SLEEVES FULLY EXTENDED AT A RIGHT ANGLE TO THE BODY (EXCEPT WHERE OTHERWISE NOTED).
DO NOT STRETCH ANY PART OF THE GARMENT!

REF. CODE	DIMENSION	MEASUREMENT DIRECTIONS
A.	<u>PLACKET WIDTH</u>	MEASURE FROM EDGE TO STITCH LINE
B.	<u>PLACKET LENGTH</u>	MEASURE FROM TOP OF PLACKET TO BOTTOM OF BOX STITCHING INSIDE AND OUTSIDE SHOULD BE EQUIDISTANCE $\pm 1/8$ "
C.	<u>SHAPED CLR FRONT</u>	MEASURE FROM TIP OF COLLAR TO COLLAR SEAM
D.	<u>SHAPED CLR BACK</u>	MEASURE FROM CENTER EDGE TO COLLAR SEAM
E.	<u>BOX PLACKET</u>	MEASURE FROM HORIZONTAL TOP STITCH LINE TO HORIZONTAL TOP STITCH LINE
F.	<u>NECK TAPE WIDTH</u>	MEASURE FROM FOLD EDGE TO STITCH LINE, TAKE SEVERAL MEASUREMENTS
G.	<u>SIDE VENT LENGTH</u>	MEASURE FROM BOTTOM HEM EDGE TO TOP OF VENT AT "V"
H.	<u>DROP TAIL</u>	MEASURE FROM BOTTOM OF FRONT EDGE TO BOTTOM OF BACK EDGE
<p>* CHECK THE SPECIAL INSTRUCTION SECTION OF THE PRODUCTION/QUALITY SPECIFICATIONS. SOME BODY LENGTH MEASUREMENTS ARE TAKEN FROM CENTER BACK NECK.</p> <p>** CHECK THE SPECIAL INSTRUCTION SECTION OF THE PRODUCTION/QUALITY SPECIFICATIONS. SOME SLEEVE OVERARM MEASUREMENTS ARE TAKEN FROM CENTER BACK NECK.</p>		

NOTE: ALWAYS CHECK THE SPECIAL INSTRUCTIONS SECTION OF THE PROD./QUALITY SPEC. BEFORE MEASURING. SPECIAL DIRECTIONS ARE LISTED FOR ANY DEVIATIONS FROM THE ABOVE STANDARD DIRECTIONS.