

MEASUREMENT DIRECTION 9401

HOW TO MEASURE BASIC "T" SHIRT

Revised 03/01/09

BEFORE MEASURING: REVIEW FIGURES 1 & 2 FOR REFERENCE!

SURFACE USED FOR GARMENT MEASURING SHOULD BE CLEAN AND SMOOTH. DO NOT USE FABRIC COVERED SURFACES FOR GARMENT MEASURING.

LAY GARMENT FLAT ON SURFACE, FACE UP, SMOOTHED WITH NO WRINKLES AND WITH SLEEVES FULLY EXTENDED AT A RIGHT ANGLE TO THE BODY(EXCEPT WHERE OTHERWISE NOTED).

DO NOT STRETCH ANY PART OF THE GARMENT!

REF. CODE	DIMENSION	MEASUREMENT DIRECTIONS
A.	<u>BODY WIDTH:</u>	MEASURE FROM LEFT-TO-RIGHT 1" BELOW BOTTOM OF ARMHOLE SEAM.
B.	<u>BODY LENGTH:</u>	MEASURE FROM JUNCTION OF COLLARETTE TO SHOULDER SEAM STRAIGHT DOWN TO BOTTOM HEM EDGE.
C.	<u>ARMHOLE LENGTH:</u>	POSITION FRONT ARMHOLE SEAM DIRECTLY OVER BACK ARMHOLE SEAM. MEASURE STRAIGHT FROM SHOULDER TO ARMHOLE SEAM DOWN TO BOTTOM
D.	<u>SLEEVE OVERARM**</u>	MEASURE FOLD EDGE OF SLEEVE FROM SHOULDER/ARMHOLE SEAM TO BOTTOM EDGE OF SLEEVE HEM.
D1.	<u>SLEEVE UNDERARM:</u>	MEASURE SEAM EDGE OF SLEEVE FROM ARMHOLE SEAM TO BOTTOM EDGE OF SLEEVE HEM.
E.	<u>SLEEVE OPENING:</u>	MEASURE FROM FOLD EDGE OF SLEEVE TO UNDERARM SEAM AT SLEEVE HEM OPENING.
F.	<u>NECK OPENING:</u>	FOLD GARMENT AT CENTER FRONT AND CENTER BACK MATCHING SHOULDER SEAMS ON TOP OF EACH OTHER. SMOOTH COLLARETTE TO BODY SEAM TO STRETCHED NECK OPENING IS MADE BY FULLY EXTENDING COLLAR TO BODY SEAM. THIS MEASUREMENT IS USUALLY DEFINED AS A MINIMUM ALLOWED.
G.	<u>NECK OPEN STR:</u>	THIS MEASUREMENT IS RARELY SPECIFIED.
H.	<u>FRONT NECK DROP:</u>	MEASURE FROM CENTER BACK COLLARETTE TO BODY SEAM, TO CENTER FRONT COLLARETTE TO BODY SEAM.
H1	<u>BACK NECK DROP:</u>	NOT DEFINED FOR THIS DIRECTION
I.	<u>NECK WIDTH:</u>	MEASURE FROM LEFT COLLARETTE TO SHOULDER SEAM, TO RIGHT COLLARETTE TO SHOULDER SEAM, STRAIGHT ACROSS.
J.	<u>COLLAR WIDTH:</u>	MEASURE FROM FOLD EDGE OF COLLARETTE TO COLLARETTE TO BODY SEAM. SEVERAL MEASUREMENTS SHOULD BE TAKEN AROUND THE NECK TO VERIFY EVEN AMOUNT OF CUT-OFF.
K.	<u>ACROSS SHOULDERS:</u>	MEASURE IN A STRAIGHT LINE FROM LEFT SLEEVE TO SHOULDER SEAM TO RIGHT SLEEVE TO SHOULDER SEAM.
L.	<u>SHOULDER WIDTH:</u>	MEASURE FROM SLEEVE TO BODY SEAM ALONG SHOULDER SEAM, TO BODY TO COLLARETTE SEAM. BOTH SIDES SHOULD BE MEASURED AND EQUAL.
M.	<u>BOTTOM HEM:</u>	MEASURE FROM FOLD EDGE OF HEM TO TOP STITCH LINE. MEASURE SEVERAL TIMES AROUND THE CIRCUMFERENCE OF THE HEM TO VERIFY EVEN WITH.
N.	<u>SLEEVE HEM:</u>	HEM SHOULD BE STRAIGHT AND STITCH LINE SHOULD NOT SHOW A DEEP BITE OR HUMP (2N CVRST). THE BOTTOM HEM MUST OVERLAP AT THE START/FINISH
P.	<u>POCKETS</u>	PLACED "X" DOWN FROM HIGH POINT OF SHOULDER, "Y" TO RIGHT OF CENTER (AS FACING)
*		CHECK THE SPECIAL INSTRUCTION SECTION OF THE PRODUCTION/QUALITY SPECIFICATIONS. SOME BODY LENGTH MEASUREMENTS ARE TAKEN FROM CENTER BACK NECK.
**		CHECK THE SPECIAL INSTRUCTION SECTION OF THE PRODUCTION/QUALITY SPECIFICATIONS. SOME SLEEVE OVERARM MEASUREMENTS ARE TAKEN FROM CENTER BACK NECK.

NOTE: ALWAYS CHECK THE SPECIAL INSTRUCTIONS SECTION OF THE PROD./QUALITY SPEC. BEFORE MEASURING. SPECIAL DIRECTIONS ARE LISTED FOR ANY DEVIATIONS FROM THE ABOVE STANDING DIRECTIONS.